

INSULATION / VOLTAGE WITHSTAND TEST **INSTRUMENT SERIES** Safety Standards





Model 3153

Automatic Insulation Voltage Withstand Testing

Voltage Control from a PC

Full Remote Control

All test parameters can be controlled by RS-232C or GP-IB, including test voltage, cut-off current, resistance threshold and timer durations. Start-stop control can be provided with the 9613 single hand remote control or 9614 two-hand remote control.

Standards-Based Testing


Comparator/Timer

Includes built-in pass-fail comparator and timer functions for easy compliance testing to various safety standards such as those for Electrical Appliance Safety Regulations.

Settable Ramp Up/Down Test Voltage Timing

Ramp Timer Functions

Raising and lowering of test voltage can be set for voltage withstand testing.



+ DANGER +

Test Status Read/Write

Program Function

Test conditions can be stored and recalled to support complete automation by sequencer. Up to 32 files can be stored with up to 50 steps per file.

Up to 32 files

Analog Voltmeter-

The test voltage can be verified not only on the digital display but also on the analog meter.

Danger Lamp

The warning light flashes during testing and whenever high voltage is present at the terminals.

External Switch-

Start/stop may be controlled with the 9613 or the 9614

(The 9613 and 9614 are options.)

Fluorescent Display Tube

The display uses a bright, easy-toread fluorescent tube.

Test Mode Selection Three test modes are selectable:

000000

- 1. Manual test modes: ACW, DCW, I
- Automatic test modes: $W \rightarrow I$, $I \rightarrow W$
- 3. Programmed test modes: testing by preprogrammed functions.

Automation Support

Automation features include programmable testing modes, EXT I/O, RS-232C, GP-IB, connection scanning and various data management functions.

Auto Discharge Feature

Any charge on the object under test is discharged by the test instrument, so there is no residual charge after testing. (DC voltage withstand, insulation resistance tests)

Save 10 Sets of Test Conditions

Store up to 10 sets of test conditions for voltage withstand and insulation resistance modes, so you can quickly switch among the test conditions. (Save/Load)

Zero-V Switching

Test voltage on/off switching can be forced to occur only at sine wave zero-crossings. (AC voltage withstand testing)

Interlock Protect Function

To ensure safety during automatic testing, test output can be interrupted and testing inhibited by input signals from automatic sensing

PWM Switching Technique

Enhanced accuracy is obtained by preventing variations in supply voltage from affecting test

Wide Range of Functions for Various Conditions

1. Pass Hold Function (0: No Hold, 1: Hold)

The pass state is held when it is activated. This is convenient for verifying the decision value.

2. Fail Hold Function (0: No Hold, 1: Hold)

The fail state is held when it is activated. This is convenient for temporarily stopping the test process.

3. Hold State (0: No Hold, 1: Hold)

This saves the state when the Stop key is pressed during a test to unconditionally end the test.

4. Momentary Out (0: Disabled, 1: Enabled)

This function outputs a voltage only when the Start key is being pressed. The Start key is effective both for EXT SW and external I/O.

5. Double Action (0: Disabled, 1: Enabled)

This function allows testing to start only if the Start key is pressed within a half second after the Stop key.

6. Fail Mode (0: Disabled, 1: Enabled)

This function allows the Hold state to be released only by the Stop key on the instrument panel.

7. "START" Interface Command (0: Disabled, 1: Enabled)

This specifies whether the "START" command is enabled.

8. Interlock Function (0: Disabled, 1: Enabled)

This specifies whether the interlock terminal for external I/O is enabled.

9. Maximum Output Voltage

Sets the upper limit of the test voltage.

10. Insulation Resistance Measurement Range

(0: Fixed Range, 1: Automatic Range)

This specifies whether the measurement range for insulation resistance testing should be fixed or automatically determined.

10111213 1415 0.0.0.0 0.0.0.0 0.0.0.0 0.0.0.0 Address specified for GP-IB control

(Various functions can be specified with the SHIFT + STOP keys)

11. Insulation Resistance Test End Mode

- 0: Test for the specified time
- 1: Stop when "pass" is detected 2: Stop when "fail" is detected

This specifies the method of ending insulation resistance tests.

12. Ramp Time Setting

0: No judgment during ramp-up

1: Judgment during ramp-up

This specifies whether the judgment is enabled during ramp-up. Valid only during voltage withstand testing.

13. PC Interface

- 0: RS-232C (PC, 9600 bps)
- 1: RS-232C (PC, 19200 bps)

This specifies the type of PC interface to use.

14. Electrical Discharge Function

(0: Disabled, 1: Enabled)

This specifies whether the electrical discharge function is enabled at the end of testing.

15. Test Signal Output

- 0: ON also when TEST indicator is flashing
- 1: OFF when TEST indicator is flashing
- 2: ON only when TEST indicator is flashing (excluding ramp down time)

This specifies whether the TEST signal of the external I/O should be output when the TEST indicator is flashing.

Enhanced System Measurements

Maximum 32-Channel Multi-Point Testing

Model 3930 HIGH VOLTAGE SCANNER

Combine Model 3153 with the 3930 HIGH VOLTAGE SCANNER to perform insulation withstand testing easily. Single-end inputs test up to 8 points (between any 4 points) per instrument, and can connect up to 4 instruments together.

Model 3930 Specifications

| No. of Channels | Multi-Mode: 4 High-Low channels |
|----------------------|-------------------------------------------------|
| No. of Channels | Single-End Mode: 8 High-Common channels |
| Operating Voltage | 5 kV AC, 7 kV DC |
| Action/Recovery Time | 6 ms or less |
| Supply Voltage | 24 V DC ±5% (at control signal input connector) |
| Size & Mass | Approx. 320(W) × 90(H) × 250(D) mm, 3 kg. |

Simultaneous Protective Ground Continuity Testing

Safety Inspection System

Combine Model 3153 with the 3157-01 AC GROUNDING HITESTER and a general-purpose sequencer for a simple safety test inspection system that includes protective ground continuity and insulation withstand testing.



Model 3157-01 AC GROUNDING HITESTER

Settable current ranges: 3.0 to 31 A AC

Max. output power:

Resistance measurement range:

A Full Line-up of Models to Suit Various Needs







EXT I/O Output Signals

External control can be provided by various signals (signal lines have photocoupler isolation)

| 1 | Pin | I/O | Signal | Function |
|---|-------|-----|----------|-------------------------------------------------------|
| ı | | | | |
| ı | 1 | OUT | READY | LO when in "ready state" |
| | 2 | OUT | L-FAIL | LO when in "fail state" for the lower bound |
| | 3 | OUT | U-FAIL | LO when in "fail state" for the upper bound |
| | 4 | OUT | PASS | LO when in "pass state" |
| ı | 5 | OUT | TEST | LO when in "test state" |
| ı | 6 | OUT | H.V.ON | LO when voltage is present at the output terminals |
| | 7 | IN | EXT-E | When LO, external I/O input signals are enabled |
| | 8 | IN | START | When LO, it functions as a "Start" key |
| | 9 | IN | STOP | When LO, it functions as a "Stop" key |
| | 10 | IN | INT.LOCK | Interlock engaged when open |
| | 11 | OUT | W-MODE | LO during voltage withstand testing |
| | 12 | OUT | I-MODE | LO during insulation testing |
| | 13 | OUT | W-FAIL | LO when in "fail state" for voltage withstand testing |
| | 14 | OUT | I-FAIL | LO when in "fail state" for insulation testing |
| ı | 15-16 | IN | ISO.GND | Ground inputs for external devices |

| Pin | I/O | Signal | Function |
|-------|-----|----------|---------------------------------------|
| 17-18 | IN | EXT.COM | Common terminals for external devices |
| 19 | OUT | STEP-END | LO when at the end of a step |
| 20 | OUT | FILE-END | LO when at the end of a file |
| 21 | IN | FILE-E | LO when FILE 0 to 4 is in use |
| 22 | IN | FILE-0 | File selection |
| 23 | IN | FILE-1 | File selection |
| 24 | IN | FILE-2 | File selection |
| 25 | IN | FILE-3 | File selection |
| 26 | IN | FILE-4 | File selection |
| 33-34 | OUT | ISO.DCV | Internal power 5V DC (60 mA) |
| 35-36 | IN | EXT.DCV | External power supply (5 to 30V DC) |

Various Function Settings

- 1. PASS Hold function
- 2. FAIL Hold function
- 3. Hold function
- 4. Momentary out
- 5. Double actions
- 6. FAIL mode
- 7. "START" interface command
- 8. Interlock function
- 9. Maximum Output Voltage
- 10. Insulation Resistance measurement range
- 11. Insulation Resistance Test End mode
- 12. Ramp Timer setting
- 13. PC Interface
- 14. Electrical Discharge function
- 15. TEST signal output

Status Out

When the output conditions set by the DIP switches are satisfied (OR condition), output is provided at relay contacts.

| ı | 1. H.V.ON | Output voltage generation |
|---|--------------|---------------------------|
| ı | 2. TEST | Testing in progress |
| i | 3. PASS | Passed |
| ı | 4. FAIL | Failed |
| | 5. INT.LOCK | Interlocked |
| | 6. READY | Ready |
| ı | 7. EXT.CONT. | Under external control |
| | 8. POWER.ON | Powers the 3159 on |

| Pin | I/O | Signal | Function |
|-------|-----|----------|-------------------------------------------------------|
| 1 | OUT | READY | LO when in "ready state" |
| 2 | OUT | L-FAIL | LO when in "fail state" for the lower bound |
| 3 | OUT | U-FAIL | LO when in "fail state" for the upper bound |
| 4 | OUT | PASS | LO when in "pass state" |
| 5 | OUT | TEST | LO when in "test state" |
| 6 | OUT | H.V.ON | LO when voltage is present at the output terminals |
| 7 | IN | EXT-E | When LO, external I/O input signals are enabled |
| 8 | IN | START | When LO, it functions as a "Start" key |
| 9 | IN | STOP | When LO, it functions as a "Stop" key |
| 10 | IN | INT.LOCK | Interlock engaged when open |
| 11 | OUT | W-MODE | LO during voltage withstand testing |
| 12 | OUT | I-MODE | LO during insulation testing |
| 13 | OUT | W-FAIL | LO when in "fail state" for voltage withstand testing |
| 14 | OUT | I-FAIL | LO when in "fail state" for insulation testing |
| 15-18 | IN | ISO.COM | Ground inputs for external devices |
| 33-36 | OUT | ISO.DCV | Internal power 15V DC (100 mA) |

| | 1. |
|---------|----|
| ound | 2. |
| ound | 3. |
| | |
| | 4. |
| ninals | 5. |
| nabled | 6. |
| key | |
| key | 7. |
| | 8. |
| ting | 9. |
| | 10 |
| testing | 10 |

- 1. PASS Hold function
- 2. FAIL Hold function
- 3. Hold function
- 4. Momentary out
- 5. Double actions
- 6. FAIL mode
- 7. "START" RS command
- 8. Interlock function
- 9. Voltage Comparator position
- 10. Insulation Resistance measurement range
- 11. Insulation Resistance Test End mode

| Pin | I/O | Signal | Function | |
|-------|-----|----------|----------------------------------------------------|--|
| 1 | OUT | READY | LO when in "ready state" | |
| 2 | OUT | L-FAIL | LO when in "fail state" for the lower bound | |
| 3 | OUT | U-FAIL | LO when in "fail state" for the upper bound | |
| 4 | OUT | PASS | LO when in "pass state" | |
| 5 | OUT | TEST | LO when in "test state" | |
| 6 | OUT | H.V.ON | LO when voltage is present at the output terminals | |
| 7 | IN | EXT-E | When LO, external I/O input signals are enabled | |
| 8 | IN | START | When LO, it functions as a "Start" key | |
| 9 | IN | STOP | When LO, it functions as a "Stop" key | |
| 10 | IN | INT.LOCK | Interlock engaged when open | |
| 15-18 | IN | ISO.COM | Ground inputs for external devices | |
| 33-36 | OUT | ISO.DCV | Internal power 15V DC (100 mA) | |

- 1. PASS Hold function
- 2. FAIL Hold function
- 3. Hold function
- 4. Momentary out
- 5. Double actions
- 6. FAIL mode
- 7. "START" RS command
- 8. Interlock function
- 9. Voltage Comparator position

Specifications

■ Voltage Withstand Testing

| | Mode AUTOMATIC INSULATION / | I 3153 WITHSTANDING HITESTER | Model 3159 INSULATION / WITHSTANDING HITESTER | Model 3158 AC WITHSTANDING VOLTAGE HITESTER |
|------------------------------|-------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------|
| | AC | DC | AC | |
| Output voltage | 0.20 to 5.00 kV | 0.20 to 5.00 kV | Two ranges: AC 0 to 2.5 or 5.0 kV | |
| Voltage output method | PWM switching method (zero-switching) | PWM switching method | Zero-sv | vitching |
| Transformer capacity | 500 VA (rated 30 minutes) | | 500 VA (rate | d 30 minutes) |
| Output capacity | | 50 VA (continuous) | | |
| Voltage adjustment method | Digital setting (0.01 | kV setting resolution) | Manual a | djustment |
| Output voltage accuracy | ±1.5% of setting | g voltage ±2 dgt. | | |
| Voltage change rate | \pm 7% or less (max. 5 kV at 100 mA \rightarrow unloaded: with resistive load)*2 | $\pm 16\%$ or less (max. 5 kV at10 mA \rightarrow unloaded: with resistive load)*2 | d: | |
| Voltage waveform | Sine wave (5% or less distortion, unloaded) | | Power waveform | |
| Voltage frequency | 50 or 60 Hz ±0.2% | | Power synchronization | |
| Output ripple voltage | | 6% of output voltage or less (at 5 kV DC, 10 mA, resistive load) | | |
| Output current | 100 mA *1 | 10 mA (continuous) | | |
| Voltmeter | Average rectified effective value display Digital: 0.00 to 5. Accuracy Analog: 0 to 5 kV Accuracy | : ±1.5% f.s. (full scale) | Average rectified effective value display Digital: 0.00 to 5.00 kV (full scale) Accuracy: ±1.5% f.s. Analog: 0 to 5 kV (full scale) Accuracy: ±5% f.s.a | |
| Current measurement range | 0.01 to 100.0 mA | 0.01 to 10.0 mA | 0.01 to 120.0 mA | |
| Indicated value range | 10 or 100 mA | 10 mA | 2, 8, 32 o | r 120 mA |
| Measurement resolution | 0.00 to 10.00 or 0.01 mA (10-n 10.1 to 100.0 or 0.1 mA (100-n | | 0.01 mA (2- or 8-mA range), 0.1 mA (32-mA range), 1 mA (120-mA range) | |
| Current measurement accuracy | ± (2% rdg. + 5 dgt.) co | mmon to each range *3 | \pm (3% f.s. + 20 $\mu A)$ for all ranges (at 5% power distortion or less) | |

^{*1.} Time vs. Output Voltage (at 23°C ambient)

■ Insulation Resistance Testing

| | Model 3153 | Model 3159 | Model 3158 |
|----------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------|
| Test voltage | Output voltage: Positive polarity 50 to 1200V DC Voltage adjustment method: Digital setting (1V resolution) Output voltage accuracy: ±1.5% ±2 dgt. of setting level | Rated voltage: 500 or 1000V DC Unloaded voltage: 1 to 1.2 times rated voltage | |
| Rated measurement current | 1 mA | 1 to 1.2 mA | |
| Short-circuit current | 200 mA or less | 4 to 5 mA (500V) 2 to 3 mA (1000V) | |
| Voltmeter | Average display Digital: 0 to 1200V DC (full scale) Accuracy: ±1.5% rdg. ±2 dgt. Analog: 0 to 1200V DC | Average display Digital: 0 to 1200V DC (f.s.) Accuracy: ±1.5% f.s. | |
| | Accuracy: ±5% f.s. (5 kV full scale) | Analog: not applicable | |
| Measurement range/accuracy | 0.100 to 1.049 MΩ 1.05 to 10.49 MΩ*1 10.5 to 104.9 MΩ*1 105 to 9999 MΩ*1 Fundamental accuracy: $\pm 4\%$ rdg.*2 | $\begin{array}{c} 0.5 \text{ to } 999 \text{ M}\Omega (500\text{V})/\pm 4\% \text{ rdg.} \\ 1 \text{ to } 999 \text{ M}\Omega (1000\text{V})/\pm 4\% \text{ rdg.} \\ 1000 \text{ to } 2000 \text{ M}\Omega/\pm 8\% \text{ rdg.} \end{array}$ | |

^{*1.} Measurement range changes according to test voltage. *2. Plus scanner accuracy, when used.

Current Measurement Range Max. Test Time Standby Time 1 ≤ 60 mA continuous none $60~mA < 1 \leq 100~mA$ 15 minutes 15 minutes

^{*2.} Unloaded = 40 M Ω load (instrument input impedance) *3. Plus scanner accuracy, when used.

■ Decision Function

| | Model 3153 | Model 3159 | Model 3158 | |
|--------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------|------------|--|
| Decision method | Window comparison method (digital specification) | Vindow comparison method (digital specification) | | |
| Decision results | UPPER-FAIL: Measured current (insulation resistance value) exceeded the specified upper bound. PASS: Measured current (insulation resistance value) was between the specified upper and lower bounds during the specified time elapsed LOWER-FAIL: Measured current (insulation resistance value) was less than the specified lower bound (Note: Model 3158 has no insulation resistance func | | | |
| Decision processing | For each decision result, output the display portion, the beeper sound, | and EXT I/O signal | | |
| Specification ranges | Voltage withstand testing: ACV: 0.1 to 100 mA (upper bound) / 0.1 to 99 mA (lower bound) DCV: 0.1 to 10 mA (upper bound) / 0.1 to 9.9 mA (lower bound) DCV: 0.1 to 10 mA (upper bound) / 0.1 to 9.9 mA (lower bound) Insulation testing: (Model 3159 only): 0.2 to 2000 MΩ (same upper/lower bounds) | | · | |
| Specification resolution | $ \begin{tabular}{lllllllllllllllllllllllllllllllllll$ | Voltage withstand testing: 0.1 mA (0.1 to 9.9 mA), 1 mA (10 to 120 mA) Insulation testing (Model 3159 only): | | |

■ Timers

| | Model 3153 | Model 3159 | Model 3158 | |
|-----------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------|------------------------|--|
| Testing timer | Specification range: 0.3 to 999 s Specification resolution: 0.1 s (0.3 to 99.9 s), 1 s (100 to 999 s) Accuracy: ±0.5% of specified value | Specification range: 0.5 to 999 s Specification resolution/accuracy: 0.1 s (0.5 to 99.9 s), ±50 ms; 1 s (100 to 999 s) ±0.5 s | | |
| | Action: (when ON is specificed) after (when OFF is specified) displayed. | starting, the countdown from the specificacys the elapsed time from starting | ïed time is displayed. | |
| Ramp timer (withstand test time) | Specification range: 0.1 to 99.9 s ramp-up and -down specified separately Specification resolution/accuracy: 0.1 s, $\pm 0.5\%$ of specified value | | | |
| Delay timer (insulation resistance test time) | Specification range: 0.1 to 99.9 s Specification resolution/accuracy: 0.1 s, ±0.5% of specified value Action: specify a delay time after testing is set to begin to inhibit decisions during that time | Non-deterministic interval: 0.5 s (Mask time until determination begins during insulation resistance testing) | | |

■ Interfaces

| | Model 3153 | Model 3159 | Model 3158 |
|---------|-----------------------------------------------------------------------------|-----------------------------------------------------------------------------------|------------|
| EXT I/O | Open-collector outputs, active low, max. 30V DC loaded voltage, all s | s, active low, max. 30V DC loaded voltage, all signal lines photocoupler-isolated | |
| EXT SW | START, STOP, SW.EN (panel terminal switch enabled), connection point inputs | | |
| RS-232C | Start-stop synchronization, full duplex, 9600 or 19200 bps | Start-stop synchronization, full duplex, 9600 bps | |
| GP-IB | IEEE 488.2 (1987) compliant | | |

■ General Specifications

| | Model 3153 | Model 3159 | Model 3158 | | | | | |
|--------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------|--|--|--|--|--|
| Display | Fluorescent display tube (digital display), analog meter | | | | | | | |
| Monitor functions | Output voltage, detected current, measured resistance Output voltage, detected current | | | | | | | |
| Monitor period | 2 times per second minimum | | | | | | | |
| Operating temperature range | 0 to 40 °C, 80% RH maximum (non-condensating) | | | | | | | |
| Storage temperature range | -10 to 50 °C, 90% RH maximum (non-condensating) | | | | | | | |
| Temperature and humidity range for guaranteed accuracy | 23 ± 5 °C, 80% RH maximum (non-condensating) (after 10-min. warm-up for 3153, or 5-min. warm-up for 3158 and 3159) | | | | | | | |
| Operating environment | Indoors, up to 2000m ASL | | | | | | | |
| Power supply voltage | 100 to 240V AC (installed fuse depends on actual voltage, so specify supply voltage when ordering) 100 to 120V AC: installed fuse 250V T10AL 200 to 240V AC: installed fuse 250V T5AL | 100V AC (3159), 120V AC (3159-01), 220V AC (3159-02), 230V AC (3159-03), 240V AC (3159-04) | 120V AC (3158-01), 220V AC (3158-03), 230V AC (3158-04), 240V AC (3158-05) | | | | | |
| Power supply frequency | 50 or 60 Hz | | | | | | | |
| Max. power consumption | n 1000 VA 800 VA | | | | | | | |
| Withstand voltage | Power supply to chassis: 1.35 kV AC at 15 mA for 1 min. | Power supply to chassis: 1.35 kV AC at 10 mA for 1 min. | | | | | | |
| Dimensions | Approx. 320 (W) \times 155 (H) \times 480 (D) mm | Approx. 320 (W) × 155 (H) × 330 (D) mm | Approx. 320 (W) × 155 (H) × 263 (D) mm | | | | | |
| Mass | Approx. 18 kg | Approx. 18 kg (3159), 20.5 kg (3159-01), 21.5 kg (3159-02 to 3159-04) | Approx. 16 kg (3158-01), 18 kg (3158-03 to 3159-05) | | | | | |
| Applicable standards | EMC: EN 61326-1:1997 + A1:1998 Class A, EN 61000-3-2:1995 + A1:1998+ A2:1998, EN 61000-3-3:1995 Safety: EN 61010-1:1993 + A2:1995 Contamination Level 2, Measurement Category II (anticipated overvoltage category 2500V) EN 61010-2-031:1994 | | | | | | | |
| Supplied accessories | 9615 H.V. TEST LEADS (high voltage side and return, one each), POWER CORD, EXTRA FUSE | | | | | | | |
| Options | 9613 REMOTE CONTROL BOX (SINGLE), 9614 REMOTE CONTROL BOX (DUAL), 9637 RS-232C CABLE (9-pin Dsub to 9-pin Dsub), 9638 RS-232C CABLE (9-pin Dsub to 25-pin Dsub), 9267 SAFETY TEST DATA MANAGEMENT SOFTWARE | | | | | | | |
| | 3930 HIGH VOLTAGE SCANNER 9151-02 GP-IB CONNECTOR CABLE (2m) 9151-04 GP-IB CONNECTOR CABLE (4m) | 9616 WARNING LAMP | | | | | | |



- Six test voltages from 25 to 1000V
- Stores 10 setting states
- Easy standards testing with comparator timer function
- Automatic electrical discharge feature
- Minimize instability with slow sampling
- Record changes with analog output



[Measurement Voltage/Range (Auto/Manual range switching)]

| [ividadar errierit Vertage, rtarige (rtate, rviandar range switching)] | | | | | | | | | | |
|------------------------------------------------------------------------|------------------|----------------------------------------|-----------------------|-----------------|------------------|--------------------------------------------|----------------|--|--|--|
| Measurement voltage | | 25V | 50V | 100V | 250V | 500V | 1000V | | | |
| Measurement range | | 2.000, 20.00 and 200.0 MΩ 2.000, 20. | | 2.000, 20.00 | and 2000 MΩ | $2.000, 20.00, 200.0$ and $4000 \ M\Omega$ | | | | |
| Accuracy | ±2% rdg. ±5 dgt. | | 0 to 20.00 M Ω | | 0 to 100.0 MΩ | 0 to 999 MΩ | | | | |
| | ±5% rdg. | 19.0 to 200.0 MΩ | | 19.0 to 2000 MΩ | 100.1 to 2000 MΩ | 1000 to 4000 MΩ | | | | |
| Unloaded voltage | | 1 to 1.2 times the measurement voltage | | | | | | | | |
| Min. meas. resistance | | 0.025 ΜΩ | 0.05 ΜΩ | 0.1 ΜΩ | 0.25ΜΩ | 0.5ΜΩ | 2ΜΩ | | | |
| Rated meas. current | | 1 to 1.2 mA | | | | | 0.5 to 0.6 mA | | | |
| Short-circuit current | | 1.2 mA or less | | | | | 0.6 mA or less | | | |

3153 AUTOMATIC INSULATION / WITHSTANDING HITESTER

Options

3930 HIGH VOLTAGE SCANNER

9613 REMOTE CONTROL BOX (SINGLE)

9614 REMOTE CONTROL BOX (DUAL)

9151-02 GP-IB CONNECTOR CABLE (2m)

9151-04 GP-IB CONNECTOR CABLE (4m)

9637 RS-232C CABLE (1.8 m) (9pin-9pin/Cross)

9638 RS-232C CABLE (1.8 m) (9pin-25pin/Cross)

9267 SAFETY TEST DATA MANAGEMENT SOFTWARE

3158-01 AC WITHSTANDING VOLTAGE HITESTER (120V AC) 3158-03 AC WITHSTANDING VOLTAGE HITESTER (220V AC) 3158-04 AC WITHSTANDING VOLTAGE HITESTER (230V AC) 3158-05 AC WITHSTANDING VOLTAGE HITESTER (240V AC)

Options

9613 REMOTE CONTROL BOX (SINGLE)

9614 REMOTE CONTROL BOX (DUAL)

9637 RS-232C CABLE (1.8 m) (9pin-9pin/Cross)

9638 RS-232C CABLE (1.8 m) (9pin-25pin/Cross)

9267 SAFETY TEST DATA MANAGEMENT SOFTWARE

INSULATION / WITHSTANDING HITESTER (100V AC)

3159-01 INSULATION / WITHSTANDING HITESTER (120V AC)

3159-02 INSULATION / WITHSTANDING HITESTER (220V AC)

3159-03 INSULATION / WITHSTANDING HITESTER (230V AC)

3159-04 INSULATION / WITHSTANDING HITESTER (240V AC)

Options

9613 REMOTE CONTROL BOX (SINGLE)

9614 REMOTE CONTROL BOX (DUAL)

9616 WARNING LAMP

9637 RS-232C CABLE (1.8 m) (9pin-9pin/Cross)

9638 RS-232C CABLE (1.8 m) (9pin-25pin/Cross)

9267 SAFETY TEST DATA MANAGEMENT SOFTWARE



REMOTE CONTROL BOX (SINGLE)



REMOTE CONTROL BOX (DUAL)





WARNING LAMP (100V AC, 0.1A)

When using Model 9616 with Models 3153 or 3158, please contact HIOKI for specific details.



HEAD OFFICE

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 / FAX +81-268-28-0568 E-mail: os-com@hioki.co.jp

HIOKI USA CORPORATION :

6 Corporate Drive, Cranbury, NJ 08512 USA TEL +1-609-409-9109 / FAX +1-609-409-9108 E-mail: hioki@hiokiusa.com

DISTRIBUTED BY

Europe Representative Office :

Meineckestrasse 48, 40474 Dusseldorf, Germany TEL / FAX +49-211-4544153 E-mail: hioki-eu@doitsu.de

Shanghai Representative Office:

Shanghai Representative Office : 1108 Union Building, 100 Yan An Road (East), Shanghai, 200002, P.R.China TEL +86-21-6328-9947/4938 FAX +86-21-6328-2064 E-mail: hioki-sh@sh.cngb.com