

2001

# INSULATION / VOLTAGE WITHSTAND TEST **INSTRUMENT SERIES** Safety Standards

Measuring Instruments





# **Model 3153**

# **Automatic Insulation Voltage Withstand Testing**

## Voltage Control from a PC

### **Full Remote Control**

All test parameters can be controlled by RS-232C or GP-IB, including test voltage, cut-off current, resistance threshold and timer durations. Start-stop control can be provided with the 9613 single hand remote control or 9614 two-hand remote control.

# **Standards-Based Testing**


## Comparator/Timer

Includes built-in pass-fail comparator and timer functions for easy compliance testing to various safety standards such as those for Electrical Appliance Safety Regulations.

# Settable Ramp Up/Down Test Voltage Timing

## **Ramp Timer Functions**

Raising and lowering of test voltage can be set for voltage withstand testing.



## Test Status Read/Write

## **Program Function**

Test conditions can be stored and recalled to support complete automation by sequencer. Up to 32 files can be stored with up to 50 steps per file.

Up to 32 files

Fluorescent Display Tube The display uses a bright, easy-to-

read fluorescent tube.

# Analog Voltmeter-

The test voltage can be verified not only on the digital display but also on the analog meter.

## Danger Lamp

The warning light flashes during testing and whenever high voltage is present at the terminals.

### External Switch-

Start/stop may be controlled with the 9613 or the 9614.

(The 9613 and 9614 are options.)

000000

Test Mode Selection
Three test modes are selectable:

- 1. Manual test modes: ACW, DCW, I
- 2. Automatic test modes:  $W \rightarrow I$ ,  $I \rightarrow W$
- Programmed test modes: testing by preprogrammed functions.

## Automation Support

Automation features include programmable testing modes, EXT I/O, RS-232C, GP-IB, connection scanning and various data management functions.

## Auto Discharge Feature

Any charge on the object under test is discharged by the test instrument, so there is no residual charge after testing. (DC voltage withstand, insulation resistance tests)

## Save 10 Sets of Test Conditions

Store up to 10 sets of test conditions for voltage withstand and insulation resistance modes, so you can quickly switch among the test conditions. (Save/Load)

## Zero-V Switching

Test voltage on/off switching can be forced to occur only at sine wave zero-crossings. (AC voltage withstand testing)

## Interlock Protect Function

To ensure safety during automatic testing, test output can be interrupted and testing inhibited by input signals from automatic sensing devices.

## PWM Switching Technique

Enhanced accuracy is obtained by preventing variations in supply voltage from affecting test voltage.

# Wide Range of Functions for Various Conditions

#### 1. Pass Hold Function (0: No Hold, 1: Hold)

The pass state is held when it is activated. This is convenient for verifying the decision value.

### 2. Fail Hold Function (0: No Hold, 1: Hold)

The fail state is held when it is activated. This is convenient for temporarily stopping the test process.

#### 3. Hold State (0: No Hold, 1: Hold)

This saves the state when the Stop key is pressed during a test to unconditionally end the test.

## 4. Momentary Out (0: Disabled, 1: Enabled)

This function outputs a voltage only when the Start key is being pressed. The Start key is effective both for EXT SW and external I/O.

#### 5. Double Action (0: Disabled, 1: Enabled)

This function allows testing to start only if the Start key is pressed within a half second after the Stop key.

## 6. Fail Mode (0: Disabled, 1: Enabled)

This function allows the Hold state to be released only by the Stop key on the instrument panel.

### 7. "START" Interface Command (0: Disabled, 1: Enabled) This specifies whether the "START" command is

8. Interlock Function (0: Disabled, 1: Enabled) This specifies whether the interlock terminal for external

#### 9. Maximum Output Voltage

enabled

I/O is enabled.

Sets the upper limit of the test voltage.

## 10. Insulation Resistance Measurement Range

(0: Fixed Range, 1: Automatic Range)

This specifies whether the measurement range for insulation resistance testing should be fixed or automatically determined.

#### 10111213 1415 0.0.0.0 0.0.0.0 0.0.0.0 0.0.0.0 Address specified for GP-IB control

(Various functions can be specified with the SHIFT + STOP kevs)

#### 11. Insulation Resistance Test End Mode

- 0: Test for the specified time
- 1: Stop when "pass" is detected
  2: Stop when "fail" is detected

This specifies the method of ending insulation resistance tests.

#### 12. Ramp Time Setting

0: No judgment during ramp-up

1: Judgment during ramp-up

This specifies whether the judgment is enabled during ramp-up. Valid only during voltage withstand testing.

#### 13. PC Interface

0: RS-232C (PC, 9600 bps)

1: RS-232C (PC, 19200 bps)

This specifies the type of PC interface to use.

#### 14. Electrical Discharge Function

(0: Disabled, 1: Enabled)

This specifies whether the electrical discharge function is enabled at the end of testing.

## 15. Test Signal Output

- 0: ON also when TEST indicator is flashing
- 1: OFF when TEST indicator is flashing
- 2: ON only when TEST indicator is flashing (excluding ramp down time)

This specifies whether the TEST signal of the external I/O should be output when the TEST indicator is flashing.

# **Enhanced System Measurements**

Maximum 32-Channel Multi-Point Testing

## Model 3930 HIGH VOLTAGE SCANNER

Combine Model 3153 with the 3930 HIGH VOLTAGE SCANNER to perform insulation withstand testing easily. Single-end inputs test up to 8 points (between any 4 points) per instrument, and can connect up to 4 instruments together.

## Model 3930 Specifications

No. of Channels	Multi-Mode: 4 High-Low channels
No. of Channels	Single-End Mode: 8 High-Common channels
Operating Voltage	5 kV AC, 7 kV DC
Action/Recovery Time	6 ms or less
Supply Voltage	24 V DC ±5% (at control signal input connector)
Size & Mass	Approx. $320(W) \times 90(H) \times 250(D)$ mm, 3 kg.

Simultaneous Protective Ground Continuity Testing

## Safety Inspection System

Combine Model 3153 with the 3157-01 AC GROUNDING HITESTER and a general-purpose sequencer for a simple safety test inspection system that includes protective ground continuity and insulation withstand testing.



Model 3157-01 AC GROUNDING HITESTER

Settable current ranges: 3.0 to 31 A AC

Max. output power: 130VA

Resistance measurement range: 0 to 1.800  $\Omega$ 

# A Full Line-up of Models to Suit Various Needs







### EXT I/O Output Signals

External control can be provided by various signals (signal lines have photocoupler isolation)

Pin	I/O	Signal	Function
1	OUT	READY	LO when in "ready state"
2	OUT	L-FAIL	LO when in "fail state" for the lower bound
3	OUT	U-FAIL	LO when in "fail state" for the upper bound
4	OUT	PASS	LO when in "pass state"
5	OUT	TEST	LO when in "test state"
6	OUT	H.V.ON	LO when voltage is present at the output terminals
7	IN	EXT-E	When LO, external I/O input signals are enabled
8	IN	START	When LO, it functions as a "Start" key
9	IN	STOP	When LO, it functions as a "Stop" key
10	IN	INT.LOCK	Interlock engaged when open
11	OUT	W-MODE	LO during voltage withstand testing
12	OUT	I-MODE	LO during insulation testing
13	OUT	W-FAIL	LO when in "fail state" for voltage withstand testing
14	OUT	I-FAIL	LO when in "fail state" for insulation testing
15-16	IN	ISO.GND	Ground inputs for external devices

Pin	I/O	Signal	Function
17-18	IN	EXT.COM	Common terminals for external devices
19	OUT	STEP-END	LO when at the end of a step
20	OUT	FAIL-END	LO when at the end of a file
21	IN	FAIL-E	LO when FILE 0 to 4 is in use
22	IN	FAIL-0	File selection
23	IN	FAIL-1	File selection
24	IN	FAIL-2	File selection
25	IN	FAIL-3	File selection
26	IN	FAIL-4	File selection
33-34	OUT	ISO.DCV	Internal power 5V DC (60 mA)
35-36	IN	EXT.DCV	External power supply (5 to 30V DC)

## **Various Function Settings**

- 1. PASS Hold function
- 2. FAIL Hold function
- 3. Hold function
- 4. Momentary out
- 5. Double actions
- 6. FAIL mode
- 7. "START" interface command
- 8. Interlock function
- 9. Maximum Output Voltage
- 10. Insulation Resistance measurement range
- 11. Insulation Resistance Test End mode
- 12. Ramp Timer setting
- 13. PC Interface
- 14. Electrical Discharge function
- 15. TEST signal output

## Status Out

When the output conditions set by the DIP switches are satisfied (OR condition), output is provided at relay contacts.

1. H.V.ON	Output voltage generation
2. TEST	Testing in progress
3. PASS	Passed
4. FAIL	Failed
5. INT.LOCK	Interlocked
6. READY	Ready
7. EXT.CONT.	Under external control
8 POWER ON	Powers the 3159 on

Pin	I/O	Signal	Function
1	OUT	READY	LO when in "ready state"
2	OUT	L-FAIL	LO when in "fail state" for the lower bound
3	OUT	U-FAIL	LO when in "fail state" for the upper bound
4	OUT	PASS	LO when in "pass state"
5	OUT	TEST	LO when in "test state"
6	OUT	H.V.ON	LO when voltage is present at the output terminals
7	IN	EXT-E	When LO, external I/O input signals are enabled
8	IN	START	When LO, it functions as a "Start" key
9	IN	STOP	When LO, it functions as a "Stop" key
10	IN	INT.LOCK	Interlock engaged when open
11	OUT	W-MODE	LO during voltage withstand testing
12	OUT	I-MODE	LO during insulation testing
13	OUT	W-FAIL	LO when in "fail state" for voltage withstand testing
14	OUT	I-FAIL	LO when in "fail state" for insulation testing
15-18	IN	ISO.COM	Ground inputs for external devices
33-36	OUT	ISO.DCV	Internal power 15V DC (100 mA)

- 1. PASS Hold function 2. FAIL Hold function 3. Hold function 4. Momentary out 5. Double actions 6. FAIL mode
  - "START" RS command
  - 8. Interlock function
  - 9. Voltage Comparator position
  - 10. Insulation Resistance measurement range
  - 11. Insulation Resistance Test End mode

Pin	I/O	Signal	Function
1	OUT	READY	LO when in "ready state"
2	OUT	L-FAIL	LO when in "fail state" for the lower bound
3	OUT	U-FAIL	LO when in "fail state" for the upper bound
4	OUT	PASS	LO when in "pass state"
5	OUT	TEST	LO when in "test state"
6	OUT	H.V.ON	LO when voltage is present at the output terminals
7	IN	EXT-E	When LO, external I/O input signals are enabled
8	IN	START	When LO, it functions as a "Start" key
9	IN	STOP	When LO, it functions as a "Stop" key
10	IN	INT.LOCK	Interlock engaged when open
15-18	IN	ISO.COM	Ground inputs for external devices
33-36	OUT	ISO.DCV	Internal power 15V DC (100 mA)

- 1. PASS Hold function
- 2. FAIL Hold function
- 3. Hold function
- 4. Momentary out
- 5. Double actions
- 6. FAIL mode
- 7. "START" RS command
- 8. Interlock function
- 9. Voltage Comparator position

# Specifications

## ■ Voltage Withstand Testing

	Mode AUTOMATIC INSULATION /	I 3153 WITHSTANDING HITESTER	Model 3159 INSULATION / WITHSTANDING HITESTER	Model 3158 AC WITHSTANDING VOLTAGE HITESTER
	AC	DC	AC	
Output voltage	0.20 to 5.00 kV	0.20 to 5.00 kV	Two ranges: AC 0 to 2.5 or 5.0 kV	
Voltage output method	PWM switching method (zero-switching)	PWM switching method	Zero-sv	vitching
Transformer capacity	500 VA (rated 30 minutes)		500 VA (rate	d 30 minutes)
Output capacity		50 VA (continuous)		
Voltage adjustment method	Digital setting (0.01	vV setting resolution)	Manual a	djustment
Output voltage accuracy	±1.5% of setting	g voltage ±2 dgt.		
Voltage change rate	$\pm$ 7% or less (max. 5 kV at 100 mA $\rightarrow$ unloaded: with resistive load)*2	$\pm 16\%$ or less (max. 5 kV at10 mA $\rightarrow$ unloaded: with resistive load)*2	d:	
Voltage waveform	Sine wave (5% or less distortion, unloaded)		Power waveform	
Voltage frequency	50 or 60 Hz ±0.2%		Power synchronization	
Output ripple voltage		6% of output voltage or less (at 5 kV DC, 10 mA, resistive load)		
Output current	100 mA *1	10 mA (continuous)		
Voltmeter	Average rectified effective value display  Digital: 0.00 to 5.00 kV (full scale)  Accuracy: ±1.5% f.s.  Analog: 0 to 5 kV (full scale)  Accuracy: ±5% f.s.		Average rectified effective value display  Digital: 0.00 to 5.00 kV (full scale)  Accuracy: ±1.5% f.s.  Analog: 0 to 5 kV (full scale)	
Current measurement range	0.01 to 100.0 mA	0.01 to 10.0 mA	Accuracy: ±5% f.s.a  0.01 to 120.0 mA	
Indicated value range	10 or 100 mA	10 mA	2, 8, 32 0	r 120 mA
Measurement resolution	0.00 to 10.00 or 0.01 mA (10-n 10.1 to 100.0 or 0.1 mA (100-n		0.01 mA (2- or 8-mA range), 0.1 m 1 mA (120-mA range)	nA (32-mA range),
Current measurement accuracy	± (2% rdg. + 5 dgt.) co	mmon to each range *3	$\pm$ (3% f.s. + 20 $\mu A) for all range$	s (at 5% power distortion or less)

<sup>\*1.</sup> Time vs. Output Voltage (at 23°C ambient)

## ■ Insulation Resistance Testing

	Model 3153	Model 3159	Model 3158
Test voltage	Output voltage: Positive polarity 50 to 1200V DC Voltage adjustment method: Digital setting (1V resolution) Output voltage accuracy: ±1.5% ±2 dgt. of setting level	Rated voltage: 500 or 1000V DC Unloaded voltage: 1 to 1.2 times rated voltage	
Rated measurement current	1 mA	1 to 1.2 mA	
Short-circuit current	200 mA or less	4 to 5 mA (500V) 2 to 3 mA (1000V)	
Voltmeter	Average display Digital: 0 to 1200V DC (full scale) Accuracy: ±1.5% rdg. ±2 dgt. Analog: 0 to 1200V DC	Average display Digital: 0 to 1200V DC (f.s.) Accuracy: ±1.5% f.s.	.:
	Accuracy: ±5% f.s. (5 kV full scale)	Analog: not applicable	
Measurement range/accuracy	0.100 to 1.049 MΩ 1.05 to 10.49 MΩ*1 10.5 to 104.9 MΩ*1 105 to 9999 MΩ*1 Fundamental accuracy: $\pm 4\%$ rdg.*2	0.5 to 999 M $\Omega$ (500V)/ $\pm$ 4% rdg. 1 to 999 M $\Omega$ (1000V)/ $\pm$ 4% rdg. 1000 to 2000 M $\Omega$ / $\pm$ 8% rdg.	

<sup>\*1.</sup> Measurement range changes according to test voltage. \*2. Plus scanner accuracy, when used.

<sup>\*2.</sup> Unloaded = 40 M $\Omega$  load (instrument input impedance) \*3. Plus scanner accuracy, when used.

Current Measurement Range Max. Test Time Standby Time 1 ≤ 60 mA continuous none  $60 \text{ mA} < 1 \le 100 \text{ mA}$ 15 minutes 15 minutes

## ■ Decision Function

	Model 3153	Model 3159	Model 3158
Decision method	Window comparison method (digital specification)		
Decision results	JPPER-FAIL: Measured current (insulation resistance value) exceeded the specified upper bound. ASS: Measured current (insulation resistance value) was between the specified upper and lower bounds during the specified time elapsed. OWER-FAIL: Measured current (insulation resistance value) was less than the specified lower bound (Note: Model 3158 has no insulation resistance function)		
Decision processing	For each decision result, output the display portion, the beeper sound, and EXT I/O signal		
Specification ranges	$\label{eq:continuous} Voltage \ with stand \ testing: \\ ACV: 0.1 \ to \ 100 \ mA \ (upper \ bound) \ / \ 0.1 \ to \ 99 \ mA \ (lower \ bound) \\ DCV: 0.1 \ to \ 10 \ mA \ (upper \ bound) \ / \ 0.1 \ to \ 9.9 \ mA \ (lower \ bound) \\ Insulation \ testing: 0.10 \ to \ 9999 \ M\Omega \ (same \ upper/lower \ bounds) \\$	$\label{eq:voltage} Voltage \ with stand \ testing: \\ 0.1 \ to \ 120 \ mA \ (upper \ bound) \ / \ 0.1 \ to \\ Insulation \ testing \ (Model \ 3159 \ only): \\ 0.2 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.2 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.3 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.4 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.5 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.6 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.7 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.8 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.8 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.8 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.8 \ to \ 2000 \ M\Omega \ (same \ upper/lower \ bound): \\ 0.9 \ to \ 2000 \ $	· · · · · · · · · · · · · · · · · · ·
Specification resolution	Voltage withstand testing: 0.1 mA (0.1 to 9.9 mA), 1 mA (10 to 100 mA) Insulation testing: 0.01 M $\Omega$ (0.10 to 9.99 M $\Omega$ ), 0.1 M $\Omega$ (10.0 to 99.9 M $\Omega$ ), 1 M $\Omega$ (100 to 9999 M $\Omega$ )	Voltage withstand testing: 0.1 mA (0.1 to 9.9 mA), 1 mA (10 to Insulation testing (Model 3159 only): 0.01 M $\Omega$ (0.2 to 2 M $\Omega$ ), 0.1 M $\Omega$ (2.1 to 200 M $\Omega$ ), 10 M $\Omega$ (210 to	to 20 MΩ),

## **■** Timers

	Model 3153	Model 3159	Model 3158
Testing timer	Specification range: 0.3 to 999 s Specification resolution: 0.1 s (0.3 to 99.9 s), 1 s (100 to 999 s) Accuracy: ±0.5% of specified value	Specification range: 0.5 to 999 s Specification resolution/accuracy: 0.1 s (0.5 to 99.9 s), ±50 ms; 1 s (100 to 999 s)	
	Action: (when ON is specificed) after (when OFF is specified) displa	starting, the countdown from the specif ays the elapsed time from starting	fied time is displayed.
Ramp timer (withstand test time)	Specification range: $0.1$ to $99.9$ s ramp-up and -down specified separately Specification resolution/accuracy: $0.1$ s, $\pm 0.5\%$ of specified value		
Delay timer (insulation resistance test time)	Specification range: 0.1 to 99.9 s Specification resolution/accuracy: 0.1 s, ±0.5% of specified value Action: specify a delay time after testing is set to begin to inhibit decisions during that time	Non-deterministic interval: 0.5 s (Mask time until determination begins during insulation resistance testing)	

## ■ Interfaces

	Model 3153	Model 3159	Model 3158
EXT I/O	Open-collector outputs, active low, max. 30V DC loaded voltage, all s	signal lines photocoupler-isolated	
EXT SW	START, STOP, SW.EN (panel terminal switch enabled), connection point inputs		
RS-232C	Start-stop synchronization, full duplex, 9600 or 19200 bps	Start-stop synchronization, full duplex	, 9600 bps
GP-IB	IEEE 488.2 (1987) compliant		

# ■ General Specifications

	Model 3153	Model 3159	Model 3158		
Display	Fluorescent display tube (digital display), analog meter	ı	I		
Monitor functions	Output voltage, detected current, measured resistance  Output voltage, detected current				
Monitor period	2 times per second minimum				
Operating temperature range	0 to 40 °C, 80% RH maximum (non-condensating)				
Storage temperature range	-10 to 50 °C, 90% RH maximum (non-condensating)				
Temperature and humidity range for guaranteed accuracy	$23 \pm 5$ °C, 80% RH maximum (non-condensating) (after 10-min. war	m-up for 3153, or 5-min. warm-up for	3158 and 3159)		
Operating environment	Indoors, up to 2000m ASL				
Power supply voltage	100 to 240V AC (installed fuse depends on actual voltage, so specify supply voltage when ordering) 100 to 120V AC: installed fuse 250V T10AL 200 to 240V AC: installed fuse 250V T5AL	100V AC (3159), 120V AC (3159-01), 220V AC (3159-02), 230V AC (3159-03), 240V AC (3159-04)	120V AC (3158-01), 220V AC (3158-03), 230V AC (3158-04), 240V AC (3158-05)		
Power supply frequency	50 or 60 Hz				
Max. power consumption	1000 VA	800	VA		
Withstand voltage	Power supply to chassis: 1.35 kV AC at 15 mA for 1 min.	Power supply to chassis: 1.35	5 kV AC at 10 mA for 1 min.		
Dimensions	Approx. 320 (W) × 155 (H) × 480 (D) mm	Approx. 320 (W) × 155 (H) × 330 (D) mm	Approx. 320 (W) × 155 (H) × 263 (D) mm		
Mass	Approx. 18 kg	Approx. 18 kg (3159), 20.5 kg (3159-01), 21.5 kg (3159-02 to 3159-04)	Approx. 16 kg (3158-01), 18 kg (3158-03 to 3159-05)		
Applicable standards	EMC: EN 61326-1:1997 + A1:1998 Class A Safety: EN 61010-1:1993 + A1:1995 Contamination Level 2, Overvoltage Category II (anticipated overvoltage category 2500V) EN 61010-1-031:1994				
Supplied accessories	9615 H.V. TEST LEADS (high voltage side and return, one each), POWER CORD, EXTRA FUSE				
	9613 REMOTE CONTROL BOX (SINGLE), 9614 REMOTE CONTROL BOX (DUAL), 9637 RS-232C CABLE (9-pin Dsub to 9-pin Dsub), 9638 RS-232C CABLE (9-pin Dsub to 25-pin Dsub)				
Options	3930 HIGH VOLTAGE SCANNER 9151-02 GP-IB CONNECTOR CABLE (2m) 9151-04 GP-IB CONNECTOR CABLE (4m)	9616 WARN	NING LAMP		



- Six test voltages from 25 to 1000V
- Stores 10 setting states
- Easy standards testing with comparator timer function
- Automatic electrical discharge feature
- Minimize instability with slow sampling
- Record changes with analog output



## [Measurement Voltage/Range (Auto/Manual range switching)]

[ividus ar of italigs (italigs (italigs switching)]							
Measurement voltage		25V	50V	100V	250V	500V	1000V
Measurement range		2.000, 20.00 and 200.0 MΩ		2.000, 20.00 and 2000 MΩ		$2.000, 20.00, 200.0$ and $4000 \ M\Omega$	
Accuracy	±2% rdg. ±5 dgt.		0 to 20.00 M $\Omega$		0 to 100.0 MΩ	0 to 999 MΩ	
	±5% rdg.	19.0 to 2	00.0 ΜΩ	19.0 to 2000 MΩ	100.1 to 2000 MΩ	1000 to 4000 MΩ	
Unloaded voltage		1 to 1.2 times the measurement voltage					
Min. meas. resistance		0.025 MΩ	0.05 ΜΩ	0.1 ΜΩ	0.25ΜΩ	0.5ΜΩ	2ΜΩ
Rated meas. current		1 to 1.2 mA					0.5 to 0.6 mA
Short-	circuit current	1.2 mA or less					0.6 mA or less

### 3153 AUTOMATIC INSULATION / WITHSTANDING HITESTER

## ■ Options

3930 HIGH VOLTAGE SCANNER

9613 REMOTE CONTROL BOX (SINGLE)

9614 REMOTE CONTROL BOX (DUAL)

9151-02 GP-IB CONNECTOR CABLE (2m)

9151-04 GP-IB CONNECTOR CABLE (4m)

9637 RS-232C CABLE (1.8 m) (9pin-9pin/Cross)

9638 RS-232C CABLE (1.8 m) (9pin-25pin/Cross)

3159 INSULATION / WITHSTANDING HITESTER (100V AC) 3159-01 INSULATION / WITHSTANDING HITESTER (120V AC) 3159-02 INSULATION / WITHSTANDING HITESTER (220V AC) 3159-03 INSULATION / WITHSTANDING HITESTER (230V AC)

3159-04 INSULATION / WITHSTANDING HITESTER (240V AC)

### ■ Options

9613 REMOTE CONTROL BOX (SINGLE)

9614 REMOTE CONTROL BOX (DUAL)

9616 WARNING LAMP

9637 RS-232C CABLE (1.8 m) (9pin-9pin/Cross)

9638 RS-232C CABLE (1.8 m) (9pin-25pin/Cross)

3158-01 AC WITHSTANDING VOLTAGE HITESTER (120V AC) 3158-03 AC WITHSTANDING VOLTAGE HITESTER (220V AC) 3158-04 AC WITHSTANDING VOLTAGE HITESTER (230V AC) 3158-05 AC WITHSTANDING VOLTAGE HITESTER (240V AC)

## Options

9613 REMOTE CONTROL BOX (SINGLE)

9614 REMOTE CONTROL BOX (DUAL)

9616 WARNING LAMP

9637 RS-232C CABLE (1.8 m) (9pin-9pin/Cross)

9638 RS-232C CABLE (1.8 m) (9pin-25pin/Cross)



REMOTE CONTROL BOX (SINGLE)



REMOTE CONTROL BOX (DUAL)





WARNING LAMP



#### HEAD OFFICE :

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 / FAX +81-268-28-0568 E-mail: os-com@hioki.co.jp

# HIOKI USA CORPORATION :

TEL +1-609-409-9109 / FAX +1-609-409-9108 E-mail: hioki@ hiokiusa.com

DISTRIBUTED BY

RCC Electronics Ltd. 1515 Matheson Blvd. E. #210 Mississauga, ON L4W 2P5 Tel: 905 238 6848 Fax: 905 238 6849

Toll Free: 1 800 668 6053 Email: rcce@rcce.com Web: www.rcce.com